



SPÍNAČ PÍSKOVÁNÍ

551, 552

551	PK	0	A	T
552	▼		▼	▼
1-2				●
3-4				●

VYPÍNAČ TOPENÍ JÍMEK

580, 581

580	0	T
581	Z	▼
1-2		●